

IMPORTANT! SAFETY INSTRUCTIONS:



READ THIS MANUAL BEFORE USING THIS APPLIANCE.



WARNING! READ ALL SAFETY WARNINGS AND INSTRUCTIONS. FAILURE TO FOLLOW THE WARNINGS AND INSTRUCTIONS LISTED BELOW MAY RESULT IN ELECTRIC SHOCK, FIRE AND/OR INJURY

- **The intended use of this appliance is explained in this manual. The use of accessories other than those recommended in this manual may present a risk of personal injury.**
- **Always check the mains voltage corresponds to the voltage on the rating plate.**
- To protect against fire and electric shock, do not immerse the cord, plug, power base or the Wet & Dry Grinder body itself in water or other liquid. Do not expose the electrical connections to water.
- The cord should be run in such a way that there will be no risk of anyone pulling it inadvertently or tripping over it.
- Do not kink, bend, squash, strain or damage the power cord and protect it from sharp edges and heat.
- Do not let the cord hang over the edge of a table or bench top. Do not let it touch hot surfaces.
- Do not pick up or operate the appliance if the power supply cord or plug is damaged, or after it malfunctions or has been dropped or damaged in any way.
- A damaged cord or plug must be replaced by the manufacturer or a qualified person in order to avoid a hazard.
- Make sure all electrical connections are clean and dry before switching on.
- Unplug the appliance from the power outlet when not in use and before cleaning, servicing, maintenance or moving the appliance.
- This appliance is not intended to be operated by means of an external timer or separate remote control system. Never touch the blades when the appliance is plugged in. The blades are very sharp. If the blades get stuck, unplug the appliance before you remove the ingredients that are blocking the blades.
- This appliance is intended for domestic use only and only use indoors.

- Improper installation and the use of accessories not recommended by the appliance manufacturer may result in fire, electric shock or personal injury.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
- Children should be supervised to ensure they do not play with the appliance. Close supervision is necessary when any appliance is used by or near children.
- Do not leave the Coffee / Spice Grinder unattended when it is switched on.
- To avoid accidents and damage to the appliance, always keep hands and kitchen utensils away from the moving blades.
- Do not remove the grinding motor until the motor has completely stopped. Always unplug at the mains when removing the blending shaft attachment.

BEFORE FIRST USE

Unpack the appliance but keep all packaging materials until you have made sure your new Wet & Dry Grinder is undamaged and in good working order.

Plastic wrapping can be a suffocation hazard for babies and young children, so ensure all packaging materials are out of their reach.

Unwind the cord to its full length and inspect it for damage. Do not use the appliance if the appliance or its cord have been damaged or are not working properly.

Read this manual to familiarise yourself with all the parts and operating principles of the Wet & Dry Grinder. Pay particular attention to the safety instructions on the previous pages.

Before using your Coffee / Spice Grinder for the first time, or following periods of prolonged storage, dismantle and rinse all parts that come into contact with food (see 'Care and Cleaning'). Dry thoroughly before assembly.

INSTRUCTIONS FOR USE

Using the Coffee / Spice Grinder

1. Remove lid from the base of the Wet & Dry Grinder.
2. Fill the stainless steel cup with the desired ingredients.
Refer to 'Grinding Suggestions' for examples and instructions.
3. Place the cover on the unit, making sure to line it up properly with the On/Off switch connections. NOTE: A safety mechanism ensures the grinder will only work when the cover is properly in place. Plug the Wet & Dry Grinder into an appropriate wall socket and switch on power to the outlet.
4. To start grinding, put one hand on top of the grinder cover and press down and hold to begin grinding. With maximum filling, grinding will take about 30 seconds. The longer you continue the operation, the finer the grind. However, do not grind continuously for any longer than 60 seconds.

5. Grind until desired consistency is achieved. To stop grinding, release pressure from the lid.
6. Unplug the grinder from the power point.
7. Gently pat the cover to remove any ground coffee/spices that may have adhered to the cover. Open the lid and your coffee/spices are now ready for us.

WARNING: DO NOT OVERFILL, USE THE COVER TO MEASURE THE QUANTITY.

CARE AND CLEANING

Before cleaning the appliance, switch it off and unplug the power plug from the wall outlet. Grip by the plug, do not pull by the cord.

Always let the Wet & Dry Grinder cool down completely before cleaning.

Do not touch the sharp blades inside the stainless steel cup.

Always clean the appliance after every use. Ensure that the Stainless steel cup with blade assembly and grinding chamber is thoroughly cleaned.

Cleaning the exterior of the unit should only be attempted with a slightly damp, soapy cloth. After wiping down the unit with the soapy cloth, dry any wet spots with a dry cloth.

Should the plastic parts become stained, rub them with a cloth dipped in a little cooking oil and then clean as usual.

Store your appliance in its original box or in a dry cupboard out of the reach of children.

WARNING: Never immerse the unit in water or any other liquid for cleaning, never wash it under running water

CAUTION: Do not put any parts of the Wet & Dry Grinder in a dishwasher. Do not attempt to dismantle the Wet & Dry Grinder. The unit contains no user-serviceable parts inside


SUGGESTED GRINDING TIMES:

INGREDIENTS:	TIME:
Black Peppercorns - 1 Tbsp	10 Seconds
Whole Cinnamon Sticks - 2 Halved	Pulse 3 times, the process for 45 seconds
Whole Cloves - 1 Tbsp	Process for 25 seconds
Anise or Fennel Seeds - 1 Tbsp	Process for 30 seconds
Flax or Sesame Seeds - 2 Tbsp	Process for 10 seconds
Nuts (to achieve chopped nuts) 70g	Pulse to roughly chop
Nuts (to achieve a fine blend) 45g	Pulse 15 times, then process for 10 Seconds
Wheat - 1/4 cup	Process for 20 seconds

Use the Cross Blade Cup for blending wet ingredients (such as preparing Guacamole/Houmous/Salsa etc) - warning DO NOT ADD TOO MUCH LIQUID - a small amount of oil or other liquid can be added to dry ingredients. It is sometimes necessary to use a small spatula or similar (do not use metal utensils) to scrape food from the sides of the cup to achieve a good result.

Use the Flat Blade Cup for blending/grinding dry ingredients (Coffee Beans etc).

PLUG:

1. This appliance has been fitted with a BS UK compliant plug which should not be replaced or removed.
2. The plug is fitted with a UK compliant fuse link which is suitable for this type of appliance and should only be replaced by a fuse link of the same rating.
3. If access to the fuse link is only possible by removing the plug cover this must only be done by a suitably qualified person.
4. If the plug or the mains cable of this appliance is damaged do not use and dispose of the appliance responsibly.
5. This appliance is a Class 2 appliance protected by double and reinforced insulation and does not require earthing. Class2 appliances are indicated by this  symbol marked on the appliance rating plate