

Fig.1

### Digital Scale BXBS0001GB & BXBS0002GB

Dear Customer

Thank you for choosing to purchase a BLACK+DECKER branded product.

#### Safety instructions

- ◆ Read this manual before using this appliance.
- ◆ **Warning!** Read all safety warnings and instructions. Failure to follow the warnings and instructions listed below may result in injury.
- ◆ The intended use of this product is explained in this manual. The use of accessories other than those recommended in this manual may present a risk of personal injury.
- ◆ For accurate results, place on a dry flat surface.
- ◆ Do NOT use scale when your body and/or feet are wet, such as after taking a bath.
- ◆ In weighing, please keep balance and do not stand on the edges or display area.
- ◆ People with disabilities or who are physically frail, should always be assisted by another person when using this scale. Use a handrail or so when stepping on the scale and make sure not to influence the measurements.
- ◆ Do NOT use chemicals to clean the scale, only a wet damp cloth.
- ◆ To ensure life of the scale, do NOT put the scale under wet and humid environments.
- ◆ Do NOT begin a weight reduction or exercise program without consulting a doctor or healthcare provider first.
- ◆ Do NOT overload, otherwise the sensor will be damaged.

- ◆ Do NOT put heavy objects on the scale whilst not in use.
- ◆ Do NOT store the scales in an upright position.
- ◆ Do NOT jump or stamp on the scale and avoid dropping, as the scale is highly precise electronic device.
- ◆ Keep out of reach of young children.
- ◆ Do NOT place the scales on a cushioned surface such as carpet or a mat.
- ◆ For indoor use only.

#### Battery Caution

Battery acid leakage can cause personal injury and cause damage to the product and surrounding property. If the battery leakage occurs, thoroughly wash any affected skin, making sure to keep battery acid away from eyes, ears, nose and mouth. Immediately wash any clothing or other surface that comes in contact with the leaked battery acid.

If chemicals burn occurs or if irritation persists, seek medical attention.

- ◆ NEVER mix old and new batteries or different brands of batteries.
- ◆ Replace all batteries at the same time.
- ◆ NEVER mix alkaline, standard (carbon-zinc), rechargeable (nickel-cadmium) batteries with this product.
- ◆ NEVER dispose of batteries in fire, as they may leak and explode.
- ◆ ALWAYS remove exhausted batteries from product.
- ◆ Batteries are inserted following the polarity markings on the product (Fig.1).

## Specifications

Power: 2 x AAA Batteries  
 Weighing Range: 2.5 - 170kg / 5 - 375lbs  
 Indexing Value: 0.1kg / 0.2lb  
 Display Mode: LCD  
 Boot Mode: Fully automatic upscale boot  
 Weighing Units: kg / lb  
 Automatic Shutdown: 10 seconds  
 Low Voltage Display: "LO"  
 Overweight: "OL"

## How To Use

- ◆ When weighing, please put the scale on a hard flat surface. In order to avoid affecting the accuracy or weighing.
- ◆ Do NOT place scales on carpets or soft flooring.
- ◆ Push the button one time to change from "KG" to "LB".




- ◆ Automatic weighing function, simple operation, convenient use, no need to switch machine to operate.
- ◆ These scales automatically shuts down after showing a steady weight value of about 10 seconds.
- ◆ After the product is unboxed, the first weighing may not be accurate, please wait for automatic shutdown and weigh again.


- ◆ When the display shows "LO" the battery is inefficient and the battery should be replaced.



- ◆ When the weighing shows "Err", it means that the weighing is wrong and should be restarted.



- ◆ When the weighing shows "OL" the product is overloaded.



## Protecting the environment



This symbol indicates that this product should not be treated as normal household waste and it should be recycled. Please take it to your nearest collection facility or for further details contact your local council or visit [www.recycle-more.co.uk](http://www.recycle-more.co.uk)

## Guarantee

BLACK+DECKER® and the BLACK+DECKER® Logo are trademarks of The Black & Decker Corporation and are used under license. Imported by Benross Marketing Limited, Liverpool, L24 9HJ, UK. Benross Marketing Ltd, italelei 1 - 2000, Antwerp, Belgium.

Benross Marketing are confident of the quality of this product and offer to consumers a 24 month guarantee from the date of purchase.

This guarantee does not impact on your statutory rights. Please retain your receipt or other proof of purchase to claim under the terms of this guarantee, you must be able to produce a proof of purchase to the seller.

For further details visit [www.blackanddecker.co.uk](http://www.blackanddecker.co.uk) or contact the customer service line +44(0)1753511234



**Customer Service Inquiries:**

---

**United Kingdom &  
Republic Of Ireland**  
www.blackanddecker.co.uk  
emeaservice@sbdinc.com

Black & Decker  
270 Bath Road  
Slough, Berkshire SL1 4DX

Tel. 01753 511234  
Fax 01753 512365

---

"Black & Decker® and Black+Decker™ and the Black & Decker® and Black+Decker™ logos are registered trademarks of The Black & Decker® Corporation and are used under license. All rights reserved.  
Manufactured by Benross Marketing Limited, L24 9HJ, Benross Marketing Ltd, italelei 1 - 2000, Antwerp, Belgium.  
MADE IN CHINA